## 1- Unplug OEM wiring from headlight



## 2- Connect OEM wiring to Amber DRL Kit



## 3- Connect Amber DRL Kit to headlight

