

Steps to Install the Quad Tips:

1. **Locate the OEM Chrome Oval Tips:**
 - The OEM chrome oval tips are located at the rear of your vehicle, one on the passenger side and one on the driver side.
2. **Remove the OEM Tips:**
 - Each chrome oval tip is secured by **four screws**.
 - Using your screwdriver or socket wrench, carefully remove the four screws from one side and set them aside.
 - Pull off the OEM tip gently.
3. **Prepare for Installation:**
 - To make the installation process easier, use a jack to **slightly lift the mufflers upward**. This will help align the new quad tips properly.
4. **Install the Quad Tips:**
 - Align the quad tip with the exhaust outlet.
 - Secure the quad tip using **three of the four screws** that were removed earlier.
 - Tighten the screws firmly but avoid over-tightening.
5. **Repeat on the Other Side:**
 - Follow the same steps for the opposite side of the vehicle.
6. **Final Check:**
 - Ensure both quad tips are securely fastened and properly aligned.
 - Lower the jack if used.