

Installation Instructions – Stainless Steel Quad Tip Inserts

**Thank you for purchasing from
PLUGNPLAYCUSTOMS!**

Follow these simple steps to install your new Stainless Steel Quad Tip Inserts:

1. Remove the OEM Chrome Oval Tips

- ☐ Locate the factory chrome oval exhaust tips at the rear of the vehicle.
- ☐ Each tip is secured with four screws.
- ☐ Use a screwdriver or socket wrench to remove all four screws per tip.
- ☐ Carefully pull off the OEM tip and set the screws aside — you'll reuse them later.

2. Attach the Stainless Steel Quad Tip Inserts

- ☐ Slide the new Stainless Steel Quad Tip Insert into the opening of the OEM chrome tip you just removed.
- ☐ The insert is held in place with two bolts.
- ☐ Use a wrench or socket to tighten the two bolts evenly. The more you tighten, the more secure the fit.

 Do not overtighten to avoid damage.

3. Reinstall the Complete Tip Assembly

- ☐ Once the insert is firmly secured, reattach the entire tip assembly (with the new quad insert inside) to the vehicle using three of the original four screws.
- ☐ Tighten securely.

4. Repeat on the Other Side

- ☐ Follow the same steps for the opposite exhaust tip.

5. Final Check

- ☐ Make sure both quad tip assemblies are properly aligned and fully secured.

You're done! Enjoy the aggressive new look.