

Steps to Install the Quad Tips:

1. Locate the OEM Chrome Oval Tips:

- The OEM chrome oval tips are located at the rear of your vehicle, one on the passenger side and one on the driver side.

2. Remove the OEM Tips:

- Each chrome oval tip is secured by **four screws**.
- Using your screwdriver or socket wrench, carefully remove the four screws from one side and set them aside.
- Pull off the OEM tip gently.

3. Prepare for Installation:

- To make the installation process easier, use a jack to **slightly lift the mufflers upward**. This will help align the new quad tips properly.

4. Install the Quad Tips:

- Align the quad tip with the exhaust outlet.
- Secure the quad tip using **three of the four screws** that were removed earlier.
- Tighten the screws firmly but avoid over-tightening.

5. Repeat on the Other Side:

- Follow the same steps for the opposite side of the vehicle.

6. Final Check:

- Ensure both quad tips are securely fastened and properly aligned.
- Lower the jack if used.

Thank you!!