

# Installation Guide PLUGNPLAYCUSTOMS Intake Shrouds

## Tools Required:

- 10mm socket or wrench
  - 8mm socket
  - Flathead screwdriver
- 

## Step-by-Step Instructions:

### 1. Remove Front Bumper

### 2. Remove OEM Intake Snorkels & Inlets

- Use a 10mm socket to remove the bolts holding the factory intake snorkels in place.

### 3. Transfer OEM Rubber Seals

- Remove rubber seals from each OEM snorkel.
- Reattach them to your new PNPCUSTOMS Intake Shrouds for a proper seal.

### 4. Install PNPCUSTOMS Shrouds

- Insert the intake shrouds and make sure they're seated flush and aligned with the OEM mounting points.

### 5. Secure with OEM Bolts

- Use the 10mm bolts from your original snorkels.
- Tighten by hand, do not overtighten, as this may damage the plastic mounting tabs.

## 6. Trim Inside part of the bumper



**Cut Here for Intake Shroud Fitment**

Should look like this after trimming. Repeat on both sides



## 7. Reinstall the Front Bumper

- Carefully line up the bumper tabs and reinstall all clips and bolts.
- Double-check fitment and panel alignment.